



A Cabrillant 600 Lock Detail

- 1 - Pilaster - variable glass.
- 2 - Receiver.
- 3 - Latch lock (variable handling).
- 4 - Lock knob.
- 5 - Indicator face plate.
- 6 - Adjustable eccentric nylon ferrule.
- 7 - Concealed rosette.

B Cabrillant 600 Hinge Detail

- 1 - Pilaster - variable glass.
- 2 - Hinge.
- 3 - Screw.
- 4 - Divider.
- 5 - Rossette.
- 6 - Adjustable eccentric nylon ferrule.

C Cabrillant Head Rail Section Detail

- 1 - Pilaster - variable glass.
- 2 - Door stop front clamp.
- 3 - Door stop rear clamp.
- 4 - Shock bracket.
- 5 - Socket head screw.
- 6 - Stabilizing bar top clamp.
- 7 - 'Puck' glass bracket.
- 8 - Stabilizing bar.

D Cabrillant 600 Foot Section Detail

- 1 - Ground rosette.
- 2 - External aluminium leg (female).
- 3 - Clamping bracket (rear).
- 4 - Clamping bracket (front).
- 5 - Pilaster - variable glass.



Door Lock



Door Hinge



Head Rail



Foot

CABRILLANT 600

Technical

